



- ☞ when installing Kordon over these penetrations use a wad punch to a pre-marked spot, ensure the Kordon fits tightly over the wrap forming a turn up lip, secure cable ties as per kd 008p



- ☞ if electrical is already connected to the meter box cut Kordon from the inside, patch with 50mm overlap minimum



- ☞ once the penetration is protected, proceed with perimeter installation.

- ☞ when installing to the perimeter of the slab, particularly in box-up type situations, you will often encounter plumbing /water /electrical pipes penetrating the slab edge. these require attention before proceeding with the perimeter installation they are wrapped prior to the concrete pour as per kd 009 approx 300mm of wrap is required

☞ penetration Kordon TB overlapping



KORDON TERMITE BARRIER



Bayer Environmental Science

Subject

conduits

Sheet No.

kd 010